


- cutters.
 4. Slide pin out.
- 5. Carefully remove the cylinder keeping the 2 pairs of white washers in place.
- 6. Slide steel piston out of swivel block.
- 7. Slip steel piston of new cylinder through swiveling block.
- Line up other end of cylinder with the Bottom Rail "T" bracket and the 2 pairs of white washers.
- 9. Slide the pin through.
- 10. Force washer over end of pin. An easy method is:
 - a. Set the vent opener down with the back of the pin supported.
 - b. Line up the washer over the end of the pin.
 - c. Set the same end of the old cylinder over the washer and hit with a hammer (as needed). The pin will push up through the hole in the old cylinder neatly seating the new washer.
- 11. Discard old cylinder.
- 12. Replace knurled adjuster and adjust for desired opening.



<u>Charley's Greenhouse</u> <u>Home Page</u>