

## SUNBLASTER


### Installation Guide - T5LED CONVERSION LAMP

## SUNBLASTER

### HORTICULTURAL LIGHTING

#### Installing your lamp

1. Switch-off power to your T5HO lighting fixture. Disconnect power at the source before installation, inspection or removal. Do not simply switch off fixture.
2. Carefully remove all existing lamps from your lighting fixture.
3. Install T5LED Conversion lamp (ensure pins are firmly seated in lamp holders).
4. Connect to power and turn on your lamp.
5. Installation is now complete.



#### Caution - Risk of fire or electric shock.

This lamp operates on all SunBlaster **T5HO** fixtures and most **T5HO** fixtures with electronic ballasts. If lamp does not light when luminaire is energized or luminaire exhibits undesirable operation (buzzing, flickering, etc.) immediately turn off and remove from power, remove lamp and contact a qualified electrician or SunBlaster.

#### Suitable for damp locations.

Suitable for use in wet locations when used in an outdoor-rated fixture. Not for use where directly exposed to the weather or water. **Not intended for use with emergency exit fixtures or dimmers.**

**Do not use if product is damaged. Do not open or modify. No user serviceable parts inside.**

SunBlaster **T5LED Conversion Lamps** are compatible with all SunBlaster **T5HO Strip Lights**.

SunBlaster **T5LED Conversion Lamps** are also compatible with most **T5HO** fixtures with electronic ballasts.